



Technical details for the Power supply

The contact named AC in is for the transformer.

In the lower row of contacts to the left is the 5V, be sure to connect the + and – correctly. To the right of the 5V is the motor outputs, also here take great care of the + and -.

The board has an LED indication of the 5V status (green).

If you do not use our heat sink the rectifier diodes **must** be mounted against similar material due to good cooling. If you have chosen to not use a heat sink which is pre-mounted by us, you have to use insulation for the TO 220 diodes otherwise a short circuit appears.

Max AC in is 28V do not exceed.